NEVI[®] GAMING DESK



With regular care and maintenance, your Herman Miller furniture will provide many years of superior performance and satisfaction. To maintain the quality of your Herman Miller product, please follow the cleaning procedures outlined here.

MATTE BLACK LAMINATE:

Wash the laminate with a soft cloth and a solution of mild detergent and warm water.

Rinse thoroughly and dry with a clean soft cloth.

For minor repair of burns or other stubborn marks, apply a nonabrasive liquid kitchen cleanser with a soft cloth soaked in warm water.

Rub in the direction of the grain; use caution to avoid damaging the surface texture or gloss.

If no grain direction is visible, rub with a light, circular motion.

Do not use powdered abrasives or other harsh cleansers like hypochlorite bleach, hydrogen peroxide, nitric or hydrochloric acids, or lye; they may deface the surface and change the finish color.



Nevi Gaming Desk 1